



Door Station

Quick Start Guide

UD47432B

Scan or tap the QR code to
access the User Manual
for detailed information.



Quick Flow Chart

1



2




3




4



Wiring and Terminal



Appearance and Accessories




Installation




Activation and Quick Configuration

1 Wiring and Terminal



2 Appearance and Accessories



No.	Name
1	IR Supplement Light
2	Microphone
3	Camera
4	Type-C Interface
5	Wiring Terminal
6	TAMPER
7	Screen
8	Loudspeaker
9	LAN (PoE)
10	Debugging Port

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.


2 Appearance and Accessories



Unit: mm [inch]


Mounting Plate

The dimension of the mounting plate is 215.87 mm (W) × 103 mm (H) × 23.5 mm (D).




Flush Mounting Gang Box

- The dimension of the gang box is 232.6 mm (H) × 119 mm (W) × 29.5 mm (D).
- The installation hole should be bigger than the actual size. The suggested dimension of the installation hole is 234.6 mm (H) × 123 mm (W) × 29.5 mm (D).




Surface Mounting Gang Box

- The dimension of the gang box is 247 mm (H) × 138 mm (W) × 17.5 mm (D).
- This gang box is not included in the package, you need to buy it separately.




3 Installation




The mounting methods and procedures are the same for some models. Here uses one as an example.

Flush Mounting




1

Carve an installation hole on the wall. The suggested dimension of the installation hole is 234.6 mm (H) × 123 mm (W) × 29.5 mm (D). Pull the cable out from the wall. The suggested length of the cables left outside is 250 mm.




2

- Insert the gang box into the installation hole. Mark the gang box screw holes' position with a marker, and take out the gang box.
 - Drill 4 screw holes according to the marks on the wall, and insert the expansion sleeves into the screw holes.
 - Fix the gang box with 4 pcs of KA4×22-SUS screws.
- Fill the gap between the gang box and the wall opening with concrete, and use tools to break off all mounting ears.



3


After you finish wiring, cover the back cover of the device, and secure it with 2 screws. Apply silicone sealant at the wiring outlet of the device.




4

Mount the door station on the wall and ensure it is securely installed. Apply waterproof sealant to the top and both sides of the device. The door station installation is now complete.


Suface Mounting with Gang Box



1



2




3


Before you begin:

- Accessories that you need to prepare for installation are in the package.
 - Make sure the power supply meets the power requirements of the door station (12 VDC).
 - Make sure all the related equipment is power-off during the installation.
- Drill holes on the wall. Insert the expansion bolts into the screw holes. Secure the surface mounting gange box to the wall using 4 pcs of KA4×22-SUS screws.
 - After you finish wiring, cover the back cover of the device, and secure it with 2 screws. Apply silicone sealant at the wiring outlet of the device.
 - Mount the door station on the wall and ensure it is securely installed. Apply waterproof sealant to the top and both sides of the device. The door station installation is now complete.


Suface Mounting with Mounting Plate



1



2



3

Before you begin:

- Accessories that you need to prepare for installation are in the package.
 - Make sure the power supply meets the power requirements of the door station (12 VDC).
 - Make sure all the related equipment is power-off during the installation.
- Drill holes on the wall. Insert the expansion bolts into the screw holes. Fix the mounting plate to the wall with 4 pcs of KA4×22-SUS screws.
 - After you finish wiring, cover the back cover of the device, and secure it with 2 screws. Apply silicone sealant at the wiring outlet of the device.
 - Mount the door station on the wall and ensure it is securely installed. Apply waterproof sealant to the top and both sides of the device. The door station installation is now complete.

4 Activation and Quick Configuration



1 Wizard

Power on and wire the network cable after installation. You should activate the device before the first login.

If the device is not activated yet, it will enter the wizard page after powering on.

Step:

- Select the system language and tap **NEXT**.
- Create a password and confirm the password to activate the device.
- Set password reset method and tap **NEXT**.

Enter the Reserved Email address, then you can reset the admin password by email.

Tap **Change to Security Question**. Select 3 security questions from default list and enter the answers of the questions, then you can reset the password by answering security questions.

- Set network parameters and tap **FINISH**.

- Set the IP address, Subnet Mask and Gateway manually.

- Enable DHCP, the device will get network parameters automatically.

Add Resident

Step:

- Hold the main page and swipe, then enter the admin password to enter the settings page.
- Tap Person Management and add users.
- Set room No. and add card, face and PIN. Select user permission to add.
- Exit the page to save the settings.

Unlock Door

The device supports unlocking via card/QR code, PIN and facial recognition.

Unlock by PIN: Enter PIN code and tap .

For other detailed information, please visit the User Manual.



Warning

- In the use of the product, you must be in strict compliance with the electrical safety.
- Regulations of the nation and region.
- CAUTION: To reduce the risk of fire, replace only with the same type and rating of fuse.
- CAUTION: This equipment is for use only with Hikvision's bracket. Use with other (carts, stands, or carriers) may result in instability causing injury.
- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)



Caution

- + identifies the positive terminal(s) of equipment which is used with, or generates direct current.
- + identifies the negative terminal(s) of equipment which is used with, or generates direct current.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- The USB port of the equipment is used for connecting to a USB flash drive only.
- The serial port of the equipment is used for debugging only.
- Burned fingers when handling the fingerprint sensor metal. Wait one-half hour after switching off before handling the parts.
- Install the equipment according to the instructions in this manual.
- To prevent injury, this equipment must be securely attached to the floor/wall in accordance with the installation instructions.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetic radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper.
- Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only.
- Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not 100% applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Please make sure that the biometric recognition accuracy will be affected by the collected pictures' quality and the light in the environment, which cannot be 100% correct.

Scan or tap the QR code to access the User Manual for detailed information.



Tips When Collecting/Comparing Face Picture


Expression

- Keep your expression naturally when collecting or comparing face pictures, just like the expression in the picture on the right.
- Do not wear hat, sunglasses, or other accessories that can affect the facial recognition function.
- Do not make your hair cover your eyes, ears, etc. and heav makeup is not allowed.




Posture

In order to get a good quality and accurate face picture, position your face looking at the camera when collecting or comparing face picture.



Size

Make sure your face is in the middle of the collecting window.



Positions When Collecting/Comparing Face Picture

Recommended Installation Height (The distance between the camera and the ground): 1.4 m to 1.6 m

