



DS-K3G411X Video Guide



Contents

1 Arm Installation	1
2 Main Switch	1
3 1100&1102 Series Card Reader	1
4 RS-485 Card Reader and QR Code Scanner	1

1 Arm Installation

Refer to the arm installation video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/3f58a930>

2 Main Switch

Refer to the main switch wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/d4bb8fd1>

3 1100&1102 Series Card Reader

Refer to the 1100&1102 series card reader installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/8250191a>

4 RS-485 Card Reader and QR Code Scanner

Refer to the RS-485 card reader and QR code scanner installation and wiring video for details:

Refer to the link to see the high-definition video: <https://enpinfodata.hikvision.com/analysisQR/showQR/7e1a9ce1>