





DS-KEP311X Series Panic Alarm Station Quick Start Guide

1 Appearance


with Camera (Unit: mm)



without Camera (Unit: mm)



Alarm Panel Descriptions




! The image is for illustrative purposes only. Please refer to the actual product.

2 Wiring

User Manual



UD43114B-B



Lead the power cable and network cable from the bottom of the device. Dig a trench and bury a conduit from the outside before connecting them to the device.

- ! Power cable and low-voltage cable should be pre-buried in separate conduits.
- The device can start working by connecting the power cable and network cable.
- The image is for illustrative purposes only. Please refer to the actual product.

3 Activation and Adding

Step 1 Activate Device

Download the client software and select **Device Management** -> **Online Devices** to find the current device. If this is your first time logging in, you need to activate it and set a login password.

Refresh Every 60s.	Export Device	Total (2)	Filter
☐ IPv4	☐ IPv6	Device Model	Firmware Model
☐ xxx-xx-xx-xx	xxxxxxxxxxxxxx	xxxxxxxxxxxxxx	Inactivate
☐ xxx-xx-xx-xx	xxxxxxxxxxxxxx	xxxxxxxxxxxxxx	Active
		Port	Boot Time
		8000	xxxx-xx-xx xxxxxx
		8000	xxxx-xx-xx xxxxxx

Step 2 Add Device

In the client software, select **Device** -> **Add Device**, and enter the device's name, IP address, user name, and password (the password you set when activating the device), then click **Add**. Default port: 8000.

Default user name: admin.

Device

Add
Online Device

Name
Connection Type

Adding Mode:
☒ IP/Domain
☐ ISUP
☐ IP Segment
☐ Hik-Connect

Add Offline Device
☐

Name

Address

TLS

Port

User Name

Password

Synchronize Time
☐


Import to Group
☐

Set the device name as the group name and add all the channels connected to the device to the group.


Add and New
Add
Cancel

4 Installation



Unit: mm




! Taking the device without camera as an example.



2 to 4 m Alarm Station Basic Specification Profile Diagram



Basic Model Dimension



Alarm Station Bottom Holes

Disconnect device of permanent connection product shall be provided as part of the building installation.

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.