DS-K3G501C(L)X Series Tripod Turnstile Video Guide

Contents

Chapter 1 Open Upper Cover 1

Chapter 2 Remove Maintenance Door 2

Chapter 3 Main Switch Installation and Wiring 3

Chapter 4 Access Board Installation and Wiring 4

Chapter 5 Card Reader Installation and Wiring 5

Chapter 6 QR Code Scanner Installation and Wiring 6

Chapter 1 Open Upper Cover

Refer to the open upper cover installation video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/4a8ce35a***

Chapter 2 Remove Maintenance Door

Refer to the remove maintenance door installation video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/c3409592***

Chapter 3 Main Switch Installation and Wiring

Refer to the main switch installation and wiring video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/b41549f3***

Chapter 4 Access Board Installation and Wiring

Refer to the access board installation and wiring video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/bb2af573***

Chapter 5 Card Reader Installation and Wiring

Refer to the card reader installation and wiring video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/eafa5a19***

Chapter 6 QR Code Scanner Installation and Wiring

Refer to the QR code scanner installation and wiring video for details:

Refer to the link to see the high-definition video: ***https://enpinfodata.hikvision.com/analysisQR/showQR/c5f11e8f***


See Far, Go Further